

Panasonic – TDA/E Handset Programming

Change Date & or Time

From the admin extension

Press: Program (on the display)

Enter password: **1234

Press: Next (on the display)

Press: Enter (shows date)

Press: enter again (shows time)

Change time

Press: Auto dial/store button to save.

Press: Hold button

Press: Exit (on the display)

