


Start Your Digital Transformation With Us.

## NEC - Handset Programming Change Extension Name

Press Speaker – dial 700 then your extension number.
Enter or change name.
Press Hold to save.
Press Speaker to exit.
Feature key = delete # = space



PH 03 5560 3333

W:wtco.com.au E: sales@wtco.com.au