

Start Your Digital Transformation With Us.

## NEC - Handset Programming Change Time

Press: Speaker


Dial: 728

Enter: The new time in 24hr

format eg for 3:30 enter 15 30

(728 15 30)

Press: Speaker to finish.



PH 03 5560 3333

W:wtco.com.au E: sales@wtco.com.au