
QUICK START GUIDE

Set up your **Wi-Fi extender**


NetComm NS-01 CloudMesh Satellite




What's **in the box**



1 x NS-01
extender



1 x ethernet
cable



1 x USB-C
power adapter




1 x quick
start guide

What **you will need**




A power point near where you want the extender



Your modem, connected to the internet

Where it **works best**



Put it in the **middle** of the area you want to cover, **no more than two rooms** from your modem.


Safety first

WHERE TO PUT IT



INDOORS ONLY

Use it inside, in the middle of the area you want to cover.




ROOM TO BREATHE

Leave at least 5 cm clear on all sides and above. Don’t cover it, shut it in a cupboard or put it behind large furniture. It may feel warm.


Safety first

POWER AND CARE



DRY AND COOL

Keep it out of direct sun, away from heat and away from water. Not for kitchens, bathrooms or laundries. Safe range is 0 to 40°C.



POWER AND KIDS

Only use the power adapter from the box, and stop using it if it is damaged. Keep small parts away from young children. There is nothing inside you can fix.


Before you begin, check your **modem is connected to the internet**.



Plug the **power adapter** into the extender, then into a power point **next to your modem**.



Keep them **close together**



Same room as the modem for now. Don’t move it yet.

Wait 5 minutes.

A **solid white or blue** light means it has joined your Wi-Fi.

A **solid red** light means move it closer to the modem.

2

What the **light means**

WHEN YOU FIRST PLUG IT IN



Red flashing
Starting up



Purple
Starting up



Blue flashing
Ready to join your modem

ONCE IT IS JOINED (SOLID LIGHT)



White
Good signal



Blue
Medium signal




Red
Poor signal. Move it closer.

Still flashing blue after 5 minutes?

Press and let go of the **WPS** button on the extender. Then, within **2 minutes**, press and let go of the **5G WPS** button on your modem.

3

Two buttons, **two minutes**




1. WPS **2. 5G WPS**

Pairing can take up to 5 minutes. Then check the light guide.

Move it to where the Wi-Fi is weak. Plug it in about **halfway**, and **no more than two rooms** from your modem. Check the light: **white** good, **blue** medium, **red** poor (move it closer).

4

Handy **extras**



LIGHTS OFF

Hold the **WPS** button on the extender for **5 seconds** to turn the light on or off.



CLOUDMESH APP

A free app for help placing the extender, Wi-Fi analytics and seeing what is connected. Search **CloudMesh** in the App Store or Google Play.

Need a hand?

Call us on **1300 765 985**

wtco.com.au

service@wtco.com.au

Local support. Australian owned.
We Transform Communications.